Sea Dream – Winterization Checklist

	BEFORE HAUL OUT:
	TOP OFF DIESEL TANK BEFORE HAULING- ADD FUEL STABILIZER & BIOCIDE
	RINSE AND PUMP WASTE TANKS DRY
	PUMP SEAWATER THROUGH HEADS OVERBOARD- CLEAN OUT ALL LINES
	PUMP WATER TANKS DRY (HOT & COLD) - CLEAN WATER STRAINER
	REMOVE SAILS
	REMOVE ALL SPARE PROPANE BOTTLES (GRILL)
	REMOVE BACKSTAY AT TRAVELIFT
	REMOVE SPEED TRANSDUCER
	CHANGE ENGINE OIL & FILTER (WHILE HOT) CAP 10 QUARTS?
	PULL RAW WATER INTAKE- FLUSH WITH 2.5 GAL OF GLYCOL ANTIFREEZE CHECK EXHAUST
	PULL STRAINER ON RAW WATER FILTER & CLEAN
	PULL RAW WATER IMPELLER
	PLUG EXHAUST PORT (TRANSOM) WITH RAG
	CHANGE TRANSMISSION FLUID CAP ~1.5 QUARTS DEXTRON III MERCON
	CHANGE FUEL FILTERS RACOR & ENGINE
	AIR INTAKE- CLEAN
	BATTERIES- CHARGE AND THEN DISCONNECT
	FRESH WATER TANKS- DRAIN (HOT & COLD), THEN RUN ANTIFREEZE- START WITH AFT HEAD SINK, SHOWER, GALLEY SINK, FWD HEAD SINK, SHOWER
	FWD HEAD- PULL SEACOCK INTAKE- RUN WASHDOWN PUMP, ADD CHEM TO TANK PUMP HEAD. OPEN SEACOCK- MOVE Y-VALVE- PUMP OVERBOARD.
	AFT HEAD- PULL SEACOCK INTAKE- ADD CHEM TO TANK, PUMP HEAD, OPEN SEACOCK- MOVE Y-VALVE- PUMP OVERBOARD.
	PULL A/C COOLANT HOSE AND RUN PUMP TO CURCULATE ANTIFREEZE- CLEAN STRAINER
	ANTIFREEZE INTO REFRIGERATOR DRAIN, FWD & AFT HEAD DRAINS
	OPEN AND CLOSE ALL SEACOCKS- MAKE SURE NO WATER IS TRAPPED IN VALVE
	RE-ENERGIZE MOISTURE ABSORBANT POUCHES
	WASH DOWN DECK & BOAT- CHECK FOR ANY LEAKS – PORTS/ETC
	REMOVE BIMINI & TIE UP SUPPORTS
	WINTER COVER- INSTALL & TIE LINES *OUTSIDE* COVER TO KEEP IT FROM INFLATING…
	REMOVE ALL CUSHIONS FROM BOAT
	CLEAN OUT ALL SEACOCKS OF BARNACLE GROWTH
	LUBE MARELON SEACOCK UNDER SINK WITH LANOLIN/WATERPROOF WINCH GREASE
	PULL APART PROP AND CHECK FOR WEAR, REGREASE. (IF REMOVING NEED PULLER 4 3/8" MIN - 3 JAWS)

Sea Dream – Winterization Checklist Continued:

	BEFORE HAUL OUT LOAD ON BOAT:
	SHOP VAC, HOSES, CONNECTOR, EXTRA FILTER
	300' GARDEN HOSE & NOZZLE TO WASH DOWN BOAT
	100' EXTENSION CORD
	LADDER & LOCK (CHAIN)
	ANTI-FREEZE BOTTLES
	OIL CHANGER PUMP
	RECYCLE OIL CONTAINER
	WINTER COVER AND SUPPORTS
	RUG TO CUSHION BOAT IN SLINGS
	OIL FOR OIL CHANGE & FILTERS
	BLOWER TO CLEAN OFF DECKS
	PARTS NEEDED FOR WINTERIZATION:
	FUEL FILTERS (YANMAR P/N 129470-55701 & RACOR P/N 2010SM)
	OIL FILTER (YANMAR P/N 129150-35150)
	2 QTS ATF DEXTRON III MERCON
	2.5 GAL 40W OIL
	15 GAL GLYCOL ANTIFREEZE (NON-TOXIC)
	FUEL STABILIZER

Sea Dream – Spring Checklist

	SPRING CLEANUP:
	GREASE MAX PROP & INSTALL NEW ZINC ON PROP AND TWO 1 1/4" ZINC'S ON THE SHAFT
	SPRAY ANTIFOULANT ON PROP
	PAINT BOTTOM ABLATIVE (1 GAL JUST COVERS)
	WAX BOAT
	GREASE ALL SEACOCKS WITH HIGH VAC SILICONE GREASE (LONG Q-TIPS)
	BRING TO BOAT BEFORE LAUNCHING:
	6 RUG STRIPS FOR TRAVELLIFT
	DAVITS (ATTIC GARAGE)
	DINK
	SAILS
	PREP FOR LAUNCH:
	RECONNECT BATTERIES
	REMOVE PLUG EXHAUST PORT (TRANSOM) RAG
	CHECK TRANSMISSION FLUID CAP ~1.5 QUARTS DEXTRON III MERCON
	CHECK ENGINE OIL
	CHECK RAW WATER IMPELLER (REPLACE/REINSTALL)
	CHECK BELT TENSION ALTERNATOR/WATER PUMP
	SPARE PROPANE BACK TO BOAT (GRILL)
	CUSHIONS BACK TO BOAT
	SAILS ON BOARD
	GPS / BINOCULARS / VHF / CHARTS
	DIVE GEAR BACK ON BOARD
	JUST BEFORE LAUNCH:
	PULL BACKSTAY FOR TRAVELLIFT
	DINK ON DAVITS
	CRANK UP CENTERBOARD
	CLOSE ALL SEACOCKS
	.
	AFTER LAUNCH:
	BURP PSS SHAFT SEAL (DRIPLESS COUPLING ON SHAFT) TO LUBRICATE & REMOVE AIR
	REPLACE WATER FILTER
	HOSE OUT BILGE AND FLUSH
	FLUSH WATER TANKS